

Product Information

Applicable product:	
10-jet tower	K-1000-H2
Required accessories:	
*Custom tower pump kit	K-1001-H2
Corner footbath OR	K-1005-H2
Alcove footbath, LH OR	K-1015-H2
Alcove footbath, RH	K-1016-H2
BodySpa alcove enclosure OR	K-5161-L
BodySpa corner enclosure	K-5162-L
*For custom component installation.	
Recommended accessories:	
BodySpa custom drain	K-7179
Fixture:	
Weight	50 lbs (22.7 kg)

Installation Notes

Install this product according to the installation guide.

Locate the keypad within the boundaries of the enclosure. 8' (2.4 m) cable is included.

The BodySpa with K-5161/K-5162 is not designed for steam applications and may not perform satisfactorily as a steam unit.

*Keyhole for keypad: Drill 3/8" (1 cm) D. hole first at top. Drill 1-5/8" (4.1 cm) D. hole second. Blind installation on backside requires 1-7/8" (4.8 cm) D. to 2-1/2" (6.4 cm) D. hole for keypad nut.

