

# KOHLER®

## Roughing-In

**K-1000-H2**  
**BODYSPA**  
**10-JET TOWER**

### Product Information

Applicable product:	
10-jet tower	K-1000-H2
Required accessories:	
*Custom tower pump kit	K-1001-H2
Corner footbath <b>OR</b>	K-1005-H2
Alcove footbath, LH <b>OR</b>	K-1015-H2
Alcove footbath, RH	K-1016-H2
BodySpa alcove enclosure <b>OR</b>	K-5161-L
BodySpa corner enclosure	K-5162-L
*For custom component installation.	
Recommended accessories:	
BodySpa custom drain	K-7179
Fixture:	
Weight	50 lbs (22.7 kg)

### Installation Notes

Install this product according to the installation guide.

Locate the keypad within the boundaries of the enclosure. 8' (2.4 m) cable is included.

The BodySpa with K-5161/K-5162 is not designed for steam applications and may not perform satisfactorily as a steam unit.

\*Keyhole for keypad: Drill 3/8" (1 cm) D. hole first at top. Drill 1-5/8" (4.1 cm) D. hole second. Blind installation on backside requires 1-7/8" (4.8 cm) D. to 2-1/2" (6.4 cm) D. hole for keypad nut.

