KOHLER Roughing-In

K-3080, K-3081 PURIST_® WALL-MOUNT CABINET/VANITY

Product Information

Installation Notes

Install this product according to the installation guide. Wall reinforcement is required.

Applicable products:	
Wall-mount cabinet	K-3080
Wall-mount vanity	K-3081



