

All information in these instructions is based on the latest product information available at the time of publication. Kohler Co. reserves the right to make changes in product characteristics, packaging, or availability at any time without notice.

DO NOT INSTALL GRIP RAILS UNTIL ALL CONSTRUCTION IS COMPLETE.

INSTALLATION:

1. Slip metal washers over bolts as shown. Thread the bolts half way into the anchor nuts pre-installed on the tub.
2. Place the appropriately-shaped gaskets over the bolts.
3. Position the grip rail so that slots line up with bolts. Be sure grip rail is placed between gasket and metal washer.
4. Position the gaskets to match contour of grip rail. Tighten the bolts evenly to secure grip rail making sure gaskets are in line with grip rail.
5. Very carefully trim excess gasket material from around grip rail with a razor blade.
6. Repeat procedure for other grip rail.

