

K-T10274, K-T10275 FORTE_® RITE-TEMP_® PRESSURE-BALANCING BATH AND SHOWER VALVE TRIM

Product Information

Applicable product:	
Bath/shower trim, sculpted lever handle, NPT spout	K-T10274-4
Bath/shower trim, traditional lever handle, NPT spout	K-T10274-4A
Bath/shower trim, sculpted lever handle, slip-fit spout	K-T10275-4
Bath/shower trim, traditional lever handle, slip-fit spout	K-T10275-4A
Bath/shower trim, script lever handle, slip-fit spout	K-T10275-4G
Rite-Temp, valve must be ordered to complete faucet.	

Lever handles are ADA compliant.	ADA
Required accessories:	
Rite-Temp _® valve without stops, NPT connections OR	K-304-K
Rite-Temp valve with stops, NPT connections OR	K-304-KS
HiFlow Rite-Temp valve with integral stops NPT connections OR	s, K-306-KS
Rite-Temp valve with PVC connections	K-304-KP

Recommended accessories:	
HiFlow Rite-Temp _® thin wall installation kit	88526
Optional accessories:	
Forte _® deep roughing-in kit for Rite-Temp _® valve (lever handles)	1025388

Installation Notes



ADA

WARNING: Risk of damage to the K-306-KS valve assembly. When using the K-306-KS valve in a fiberglass or acrylic installation, use the thin wall installation kit (88526).

Install this product according to the installation guide.

Install the Rite-Temp valve according to the valve installation

Avoid cross-flow conditions. Do not install shut-off device on either valve outlet.

Cap shower outlet if deck-mounted spout, diverter, or handshower is connected to the spout outlet.

Install straight pipe or tube drop of 7" (17.8 cm) to 18" (45.7 cm) with single elbow between valve and wall-mount spout.



