



NOTE: SEE PARTS LIST FOR LINK TO BURNER PARTS BREAKDOWN.

**Fastener/Screw Legend**

Motor Band Bolt	1/4-20 x 1.50 Grade 5 or Higher
Motor Leg Bolt	1/4-20 x 1.25 w/washer, Thread Forming
Flue Collar/Burner Mount Screws	#10 x .75 Type AB
Cleanout Cover Screws	#8 x .50 Type AB S.S.
Standard Cabinet Screws	#8 x .50 Type AB S.H.

**LBR80CSERIES-D**

The following parts are in 42237-012 RLBR80B140/168D20-3:						
Ref #	Part #	Description	Status	Qty	Price	Additional Info
20	R40344-094	5780 ELECTRODE KIT	Active	1	☒	
23	R40344-093	7006 CAD CELL	Active	1	☒	
48	35K71	R41924-002 COMBUSTION CHAMBER	Active	1	☒	
50	11M40	R02379A006 FAN - LIMIT CONTROL	Active	1	☒	
68	R37400D054	TL501JJ-2	Not Available	1	☒	
69	R40387-001	MOTOR 3/4 HP, 1 PHASE	Not Available	1	☒	
71	R38180C001	BAND-MOTOR MOUNTING	Not Available	1	☒	
72	R07408B008	ARM-MOTOR MOUNTING	Not Available	4	☒	
73	R02592A013	WHEEL-BLOWER	Not Available	1	☒	
74	R02581C046	ASSY-BLOWER HOUSING	Not Available	1	☒	
75	R30123C006	LEG-BLOWER (11)	Not Available	1	☒	
76	R30123C006	LEG-BLOWER (11)	Not Available	1	☒	
86	RS39232D008	12.5MFD@370V CAP. & BOOT	Active	1	☒	
96	R37818B001	INSULATION-MTG PLATE BRNR	Limited Availability	1	☒	
97	R41992-003	ARM-401 BURNER	Active	1	☒	
98	R05640B026	NOZZLE-OIL BRN 1.10/80 B	Active	1	☒	
98	86H39	R05640B014 NOZZLE-OIL BURNER	Active	1	☒	
99	R40344-066	7190U PROTECTORELAY	Active	1	☒	
100	R01207B001	CONTROL-DRAFT	Active	1	☒	
101	R32227B000	PLATE-INNER POUCH	Active	1	☒	
102	R41967-004	WELDMENT-FLUE PIPE	Not Available	1	☒	
104	36K17	R39765B001 GASKET-FLUE	Active	1	☒	
106	R41963-001	GASKET-COVER PLATES	Not Available	3	☒	
109	R41966-001	3811 GASKET-BURNER	Active	1	☒	
121	R07489B001	RELAY	Not Available	1	☒	
127	R38543B010	FILTER	Not Available	1	☒	
130	R41809-002	LABEL-WIRING DIAGRAM	Not Available	1	☒	
132	R38937B001	GASKET-FLUE PIPE	Not Available	1	☒	
135	R41812-001	COVER-OBSERVATION	Active	1	☒	
136	R41811-001	COVER-CLEANOUT	Active	2	☒	
138	R41821-001	WELDMENT-BURNER MTG	Active	1	☒	

