



NOTE: SEE PARTS LIST FOR LINK TO BURNER PARTS BREAKDOWN.

Fastener/Screw Legend	
Motor Band Bolt	1/4-20 x 1.50 Grade 5 or Higher
Motor Leg Bolt	1/4-20 x 1.25 w/washer, Thread Forming
Flue Collar/Burner Mount Screws	810 x .75 Type AB
Cleanout Cover Screws	88 x .50 Type AB S.S.
Standard Cabinet Screws	48 x .50 Type AB S.W.

The following parts are in 42236-005 RLHF80B84/95D12-3:						
Ref #	Part #	Description	Status	Qty	Price	Additional Info
20	R40344-094	5780 ELECTRODE KIT	Active	1		
23	R40344-093	7006 CAD CELL	Active	1		
38	R42510-003	HEAT EXCHANGER	Active	1		
48	35K70	R41917-002 COMBUSTION CHAMBER	Active	1		
50	21W96	R36604B001 CONTROL-FAN & LIMIT	Active	1		
53	36K14	R01851A017 CONTROL-LIMIT	Active	1		
68	R37400D084	TL501GGG-1	Not Available	1		
69	36K20	R47463-001 MOTOR-BLOWER	Active	1		
71	98M75	R07407B000 BAND - MOTOR MOUNT	Active	1		
72	33H36	R07408B003 ARM-MOTOR MTG	Active	3		
73	76K01	R02592A006 WHEEL-BLOWER	Active	1		
74	36K27	02581C057 HOUSING-BLOWER	Active	1		
75	R33328C014	RAIL-BLOWER SUPPORT	Active	1		
86	RS39232D004	7.5MFD@370V CAPAC. & BOOT	Active	1		
92	R41992-001	ARM201 OIL-BURNER	Active	1		
98	33H06	R37818B001 GASKET	Active	1		
97	R41992-001	ARM201 OIL-BURNER	Active	1		
98	R05640B008	NOZZLE-OIL BRN .65/80 B	Active	1		
98	45H42	R05640B010 NOZZLE-BURNER	Active	1		
99	R40344-066	7190U PROTECTORELAY	Active	1		
100	R01207B001	CONTROL-DRAFT	Active	1		
101	R32227B000	PLATE-INNER POUCH	Active	1		
106	35K72	GASKET	Active	3		
109	R41966-001	3811 GASKET-BURNER	Active	1		
121	22W04	R07489B001 RELAY-BLOWER DPST	Active	1		
130	R41809-002	LABEL-WIRING DIAGRAM	Not Available	1		
131	R41916-001	SMOKE-COLLAR FLANGE (1)	Active	1		
132	35K56	R38937B001 GASKET	Active	1		
135	R41812-001	COVER-OBSERVATION	Active	1		
136	R41811-001	COVER-CLEANOUT	Active	2		
138	R41821-001	WELDMENT-BURNER MTG	Active	1		

