



Model / Modelo / Modèle
R2707, R2707-PX, R2707-MF

R2707
 (Solder)
 (Suelde)
 (Brasage)




RP40510
 End Valve Assembly
 Ensemble de la
 válvula final
 Soupape

R2707-PX
 (PEX Crimp)
 (Engarce de la tubería de PEX)
 (PEX - raccordement par sertissage)




RP78942
 End Valve Assembly
 Ensemble de la
 válvula final
 Soupape
 (no clips)


R2707-MF
 (PEX Cold Expansion)
 (Expansión de la tubería de PEX en frío)
 (PEX - raccordement par dilatation à froid)



RP78941
 End Valve Assembly
 (No Clips)
 Ensemble de la
 válvula final
 (No Ganchos)
 Soupape
 (no clips)



RP78940
 Clips (6)
 Ganchos (6)
 Clips (6)



RP40505
 Top Washer
 Arandela superior
 Rondelle supérieure

RP40503
 Jack Screw
 Gato de Tornillo
 Vis d'ajustement

RP40507
 Bottom Washer
 Arandela Inferior
 Rondelle inférieure

RP6060
 Bonnet Nut
 Bonete
 Chapeau


RP24096
 Stem Assembly
 Ensemble de la
 unidad de la espiga
 Obturateur

RP4993
 Seat and Spring
 Asiento y Resorte
 Siège et ressort

RP78946
R2707-PX
 Spout Adapter Assembly
 Ensemble del Adaptador/
 Desviador del Tubo de Salida
 Adaptateur/Dérivation du bec

RP78945
R2707-MF
 Spout Adapter Assembly
 Ensemble del Adaptador/
 Desviador del Tubo de Salida
 Adaptateur/Dérivation du bec

RP40509
R2707 (Solder / Suelde / Brasage)
 Spout Adapter Assembly
 Ensemble del Adaptador del Tubo de Salida
 Adaptateur du bec




RP40617
 Test Cap
 Tapa de prueba
 Bouchon d'essai

RP40504
 Top Washer
 Arandela superior
 Rondelle supérieure

RP40503
 Jack Screw
 Gato de Tornillo
 Vis d'ajustement


RP40506
 Bottom Washer
 Arandela Inferior
 Rondelle inférieure

RP18362
 O-Ring
 Anillo "O"
 Joint torique



RP18361
 Tee (Solder)
 Codo T (Solder)
 Raccord en T (Solder)

RP78939
 Tee (PEX-PX)
 Codo T (PEX-PX)
 Raccord en T (PEX-PX)



RP78938
 Tee (PEX-MF)
 Codo T (PEX-MF)
 Raccord en T (PEX-MF)