

Item	Part Number	Description
Bowls		
А	100-0090RG-R	Orange ABS Plastic Bowl
	100-009GRN-R	Green ABS Plastic Bowl
	100-009YEL-R	Yellow ABS Plastic Bowl
	100-008R	Stainless Steel Bowl
	AP100-011A	Stn. Stl. Flanged Bowl For Deck Mount


Drain Plate Assemblies		
В	AP150-012A	Drain Plate Assembly for Plastic Bowls
	AP150-012B	Drain Plate Assembly for Stainless Bowls
	Note: Includes Drain Plate, Cupped Washer, And Gasket	

Waste Receptors

•		
С	150-014E-2	Cast Aluminum Waste Receptor for Wall Mount Units
	150-066-2	Cast Aluminum Waste Receptor for Pedestal Units

Ball Valve Assemblies

D	AP600-101H	1/2"IPS Stay-Open Chrome Plated Brass Ball Valve with Flag Handle, Horizontal
	AP600-101V	1/2"IPS Stay-Open Chrome Plated Brass Ball Valve with Flag Handle, Vertical
	AP600-101H-HFC	1/2"IPS Stay-Open Chrome Plated Brass Ball Valve with Flag Handle, for Hand/ Foot Control, Horizontal
	AP600-101V-HFC	1/2"IPS Stay-Open Chrome Plated Brass Ball Valve with Flag Handle, for Hand/ Foot Control, Vertical
	AP600-104	1/2" IPS Brass Stay-Open Ball Valve, Push- Down Control
E	AP050-010	Stainless Steel Foot Treadle and Return Spring with Aluminum Clevis Pin
F	150-032	Powder Coated Cast Aluminum Floor Flange, 1-1/4" NPT Female Connection
G	AP470-021	FS-Plus™ Spray Head Assy.
Н	AP470-110R	(2) FS-Plus™ Spray Heads with Chrome Plated Brass Fittings
I	BI136-02-04	3/8" IPS X 2-1/4" Brass Shank
·		•










This guardian equipment product is equipped with GS-Plus™ spray heads. Each head features:

- Tough polypropylene plastic construction
- Highly visible integrated nylon dust cover
- Easily accessible 3.2 GPM flow control
- Dense (60 pore per inch) polyurethane filter
- Unique design provides a consistently soft, full spray of water across a range of working pressures from 30 to 100 psi.

Item	Part Number	Description
А	AP470-021	FS-Plus™ Spray Head (assembled)
В	AP470-022R	Dust Cover and Cap Assembly
С	470-024R	60 PPI Polyurethane Filter
D	470-025R	3.2 GPM Flow Control








IMPORTANT

In order to operate properly, the flow control must be inserted into the body *concave end first.*





312 447 8100 теlephone 312 447 8101 ғасsіміle gesafety.com (D)