




HD100



HD100 Parts List

| Ref | Part Number | Item | Description | Qty | Weight each |
|-----|--------------|-------|------------------------|-----|-------------|
| 1 | 5H0800470001 | 48820 | ACCESS PANEL | 1 | 8 |
| 2 | 5H0750150001 | 48777 | Burner | 1 | 1 |
| 3 | 5H0799240001 | 48811 | BURNER BOX | 1 | 1.1 |
| 5 | 5H0798060001 | 48804 | GASKET (COLLECTOR BOX) | 1 | 1 |
| 7 | 5H0628920045 | 48821 | DEFLECTOR BLADE | 1 | 1 |
| 9 | 5H0798020000 | 53667 | FAN | 1 | 4 |
| 10 | 5H0797430005 | 53664 | FANGUARD | 1 | 1.1 |
| 11 | 5H0799250001 | 48812 | BURNER BRACKET | 1 | 1 |
| 12 | 5H0750020005 | 53652 | FLAME ROLLOUT SWITCH | 1 | 1 |
| 14 | 5H0750310000 | 32242 | FLAME SENSOR | 1 | 1 |
| 15 | 5H0799270001 | 48814 | FRONT PANEL | 1 | 6 |
| 16 | See Table | | GAS VALVE | 1 | |
| 17 | See Table | | HEAT EXCHANGER KIT | 1 | |
| 19 | 3H0400780001 | 53668 | HIGH LIMIT SWITCH | 1 | 1 |
| 20 | 5H0799280001 | 56086 | MANIFOLD ASSY 1/2" | 1 | 1.1 |
| 21 | 9F0302200000 | 53801 | MOTOR | 1 | 12 |
| 23 | See Table | | ORIFICE SPUD | 1 | |
| 24 | | | NOT USED | 1 | |



HD100 Parts List

| Ref | Part Number | Item | Description | Qty | Weight each |
|-----|--------------|-------|---------------------------------|-----|-------------|
| 25 | 3H0373620002 | 56183 | POWER EXHAUST ASSEMBLY | 1 | 9 |
| 26 | 5H0794410009 | 53663 | PRESSURE SWITCH | 1 | 1 |
| 27 | 3H0384620001 | 65702 | SIDE PANEL W/ HEAT SHEILD | 1 | 10 |
| 28 | See Table | | IGNITION CONTROL | 1 | |
| | 5H0842290003 | 69230 | 3AMP FUSE | 1 | 1 |
| 29 | 5H0862800000 | 59336 | SPRING | 1 | 1 |
| 30 | 5H0750290000 | 32237 | CONTROL TRANSFORMER | 1 | 2 |
| 31 | 5H0799050000 | 48805 | UNIT MOUNTING BRACKET | 1 | 2 |
| 34 | | | NOT USED | 1 | |
| 35 | | | NOT USED | 1 | |
| 37 | 5H0799210001 | 48808 | BOTTOM PANEL | 1 | 42 |
| 38 | 5H0799190001 | 48806 | REAR PANEL | 1 | 28 |
| 39 | 5H0799200002 | 53740 | Top panel | 1 | 40 |
| 40 | 5H0796360000 | 48795 | IGNITOR--DIRECT SPARK | 1 | 2 |
| - | See Table | | IGNITION CABLE | 1 | |
| - | 5H0798510003 | 53771 | OUTLET COLLAR | 1 | 1 |
| - | 5H0797940000 | 48801 | GASKET (POWER EXHAUSTER) | 1 | 1 |
| - | 5H0749970008 | 53651 | INSULATION (SIDE PANEL) | 1 | 1.1 |
| - | 5H0749970005 | 48830 | INSULATION (TOP, BOTTOM PANELS) | 1 | 1.1 |
| - | 5H0749970006 | 53650 | INSULATION (TOP, BOTTOM PANELS) | 1 | 1.1 |
| - | 5H0799610001 | 48815 | COLLECTOR BOX | 1 | 1.1 |
| - | 5H0797470000 | 48799 | CONTROL PANEL | 1 | |
| - | 5H0751850140 | 53657 | SILICON TUBE 1/4" ID | 1 | 1 |

Heat Exchanger HDB

| Exchanger Type | Heat Exchanger |
|-----------------|----------------|
| Aluminized | 3H0373601005 |
| Stainless Steel | 3H0373602005 |

Gas Control Parts HDB Large

| Gas Type | Gas Control Type | Gas Valve | Orifice | Ignition Control | Ignition Cable |
|----------|------------------|--------------|--------------|------------------|----------------|
| Natural | 1 Stage | 5H0797510000 | 5H0750260045 | 5H0797490000 | 5H0796892160 |
| Propane | 1 Stage | 5H0798690000 | 5H0750260055 | 5H0797490000 | 5H0796892160 |
| Natural | 2 Stage | 5H0797480000 | 5H0750260045 | 5H0798040000 | 5H0796892160 |



HD100

Parts List

Gas Control Parts HDB Large

| Gas Type | Gas Control Type | Gas Valve | Orifice | Ignition Control | Ignition Cable |
|----------|------------------|--------------|--------------|------------------|----------------|
| Propane | 2 Stage | 5H0798710000 | 5H0750260055 | 5H0798040000 | 5H0796892160 |