



Bill of Materials

REF #	PART #	NAME	NOTES
0	5H74997-8	Insulation (side panel)	
0	5H74997-5	Insulation (top, btm panels)	
0	5H74997-6	Insulation (top, btm panels)	
0	5H79689-2160	Ignition Cable	
0	5H75002-5	High Limit Switch (surface mount)	
0	5H79794	Gasket (Power Exhauster)	
0	5H79851-4	Collar (Inlet)	
0	5H79851-3	Collar (Outlet)	
0	5H75185-120	Silicon Tube 1/4" ID	
0	5H79793-1	Gasket	(Inlet & Outlet Collars)
1	5H80047-1	Access Panel	
2	5H75015-2	Burner	

3	5H79924-1	<b>Burner Box</b>	
5	5H79806-1	<b>Gasket (Collector Box)</b>	
7	5H62892-45	<b>Deflector Blade</b>	
9	5H79802-1	<b>Fan</b>	
10	5H79743-5	<b>Fan guard</b>	
11	5H79925-1	<b>Burner Bracket</b>	
12	5H75002-4	<b>Flame Rollout Switch</b>	More common replacement part
14	5H75031	<b>Flame Sensor</b>	More common replacement part
15	5H79927-1	<b>Front Panel</b>	
16	5H79751	<b>Gas Valve Natural Gas</b>	1 Stage
16	5H79748	<b>Gas Valve Natural Gas</b>	2 Stage
16	5H79869	<b>Gas Valve Propane Gas</b>	1 Stage
16	5H79871	<b>Gas Valve Propane Gas</b>	2 Stage
17	3H37360-1005	<b>Heat Exchanger Kit</b>	Aluminized
17	3H37360-2005	<b>Heat Exchanger Kit</b>	Stainless Steel
19	5H75769-2	<b>High Limit Switch (stalk mount)</b>	
20	5H79928-1	<b>Manifold</b>	ASSY1/2"
21	9F10270	<b>Motor (Fan)</b>	More common replacement part
23	5H75026-45	<b>Orifice Natural Gas</b>	
23	5H75026-55	<b>Orifice Propane (LP) Gas</b>	
25	3H37362-2	<b>Power Exhaust Assembly</b>	
26	5H79441-9	<b>Air Pressure Switch</b>	More common replacement part
27	5H79922-1	<b>Side Panel</b>	
28	5H79804	<b>Ignition Control</b>	2 Stage
28	5H79749	<b>Ignition Control</b>	1 Stage
29	5H56761	<b>Spring</b>	
30	5H75029	<b>Control Transformer</b>	More common replacement part
31	5H79905	<b>Unit Mounting Bracket</b>	

34	9F33217	<b>Motor</b>	
35	5H100099	<b>Blower Assembly</b>	
37	5H79921-1	<b>Bottom Panel</b>	
38	5H79919-1	<b>Rear Panel</b>	
39	5H79920-1	<b>Top Panel</b>	
40	5H79636	<b>Ignitor, Direct Spark</b>	More common replacement part