




B-1120, B-1120-LN, B-1121, B-1122, B-1123

Model B-1120-LN does not include nozzle assembly (059X). Model B-1121 includes a 8" nozzle (060X). Model B-1122 includes a 10" nozzle (061X). Model B-1123 includes a 12" nozzle (062X).



Faucet Assembly

| | | | | | |
|---|----------------------------|-----------|----|---------------------------------|-----------|
| 1 | Screw, Lever Handle | 000922-45 | 8 | Washer | 000999-45 |
| 2 | Index, Button, Blue/Cold | 001660-45 | 9 | Locknut | 002954-45 |
| | Index, Button, Red/Hot | 001661-45 | 10 | Asm, Swing Nozzle, 6" (B-1120) | 059X |
| 3 | Handle, Lever | 001638-45 | | Asm, Swing Nozzle, 8" (B-1121) | 060X |
| 4 | Asm, Spindle NSF - RH/Cold | 009753-25 | | Asm, Swing Nozzle, 10" (B-1122) | 061X |
| | Asm, Spindle NSF - LH/Hot | 009754-25 | | Asm, Swing Nozzle, 12" (B-1123) | 062X |
| 5 | Seat | 000763-20 | 11 | Washer | 009538-45 |
| 6 | Locknut, Cover Plate | 000712-25 | 12 | Sleeve | 011429-45 |
| 7 | Escutcheon, Body | 001259-40 | 13 | O-Ring | 001074-45 |

