


# BL-5700-08



## Faucet Assembly

1	Nozzle	000387-40	8	Handle, Lab 4-Arm	000059-40
2	Asm, Vaccum Breaker	B-0968	9	Asm, Spindle Eterna	005960-45
3	Tip, Serrated, Straight	BL-5550-04	10	Washer	002290-45
4	Nipple, 3/8" x 7"	000363-40	11	Locknut	000965-45
5	Asm, Base Faucet	007253-40	12	Nut, Coupling, Spreader	000736-20
6	Screw, Handle	000925-45	13	Asm, Spreader Unit	002898-40
7	Index, Snap-In, Dark Green	001191-45	14	Tailpiece	001592-20
	Index, Snap-In, Red	001194-45	15	Nut	000958-20

