

Ordering Information

| | |
|--|------------|
| Mexico faucets and fittings have an M after the first sequence of numbers (such as K-12345 M) | |
| Project pack models, where applicable, are denoted by a P , (such as K- P 12345) | |
| Applicable shower faucet trim only: | |
| With acrylic handle* | K-T15611-7 |
| *Valve must be ordered to complete faucet. | |

| | | |
|--|----------|-------------|
| Applicable valve: | | |
| Rite-Temp valve without stops | K-304-K | not shown** |
| Rite-Temp valve with stops | K-304-KS | not shown** |
| HiFlow Rite-Temp valve with integral stops | K-306-KS | not shown** |
| Non-pressure valve without stops | K-308-K | not shown** |
| Non-pressure valve with stops | K-308-KS | not shown** |

Ordering Information

| | | |
|---|-------|-----------|
| HiFlow Rite-Temp thin wall installation kit | 88526 | not shown |
| **Required for configuration illustrated. | | |

Installation Notes

Avoid cross-flow conditions. Do not install shut-off device on either valve outlet.

Cap shower outlet if deck-mount spout, diverter, or handshower is connected to spout outlet.

Install straight pipe or tube drop of 7" (17.8cm) to 18" (45.7cm) with single elbow between valve and wall-mount spout.

