

## **Anti-Siphon Auto Vent**

- Air automatically enters drain line for proper venting, then the spring-loaded seal closes after drainage to prevent escape of sewer gases
- For secondary venting only. Each drainage system must have a main vent stack
- To be installed in a readily accessible location with free flow of air, never in a sealed wall cavity

	Item No.	Description	Min. Qty.	Case Qty.	
		BULK			
Ī	239	1½" MIP vent, ABS	50	50	
		BAR-CODED BAGS IN A CUT CASE BOX			
	239PK2	1½" MIP vent, ABS, 1/bag	10	10	

