

Underground - Couplings

Copper Pipe Size (CPS) Coupling



Part No.	Description	Pkg. Qty.	Lb./Box
CUCPL-1/4	1/2" CTS x 1/4" Copper to Coupling	1 Ea.	0.3
CUCPL-1/2	1/2" CTS x 1/2" Copper to Coupling	1 Ea.	0.3
CUCPL-3/8	1/2" CTS x 3/8" Copper to Coupling	1 Ea.	0.3
PE90CPL-8	1/2" CTS 90 Degree Coupling	1 Ea.	0.4
PECPL-8	1/2" CTS Coupling	1 Ea.	0.2
PECPL-8-16	1/2" CTS x 1" CTS Reducer Coupling	1 Ea.	0.5
PECPL-16	1" CTS Coupling	1 Ea.	0.5
PERCPL-8	1/2" CTS Repair Coupling	1 Ea.	0.4

IPS/CTS Reducer Couplings



Part No.	Description	Pkg. Qty.	Lb./Box
PECPL-8-12	1/2" CTS x 3/4" IPS Reducer Coupling	1 Ea.	0.4
PECPL-8-16-IPS	1/2" CTS x 1" IPS Reducer Coupling	1 Ea.	0.8
PECPL-16-16-IPS	1" CTS x 1" IPS Reducer Coupling	1 Ea.	0.8

Iron Pipe Size (IPS) Couplings



Part No.	Description	Pkg. Qty.	Lb./Box
PE90CPL-12	3/4" IPS 90 Degree Coupling	1 Ea.	1.0
PECPL-12	3/4" IPS Coupling	1 Ea.	0.5
PECPL-12-16-IPS	3/4" IPS x 1" IPS Reducer Coupling	1 Ea.	0.7
PECPL-12-20	3/4" IPS x 1-1/4" IPS Reducing Coupling	1 Ea.	2.0
PECPL-16-IPS	1" IPS Coupling	1 Ea.	0.8
PECPL-16-IPS-20	1" IPS x 1-1/4" IPS Reducer Coupling	1 Ea.	1.7



Part No.	Description	Pkg. Qty.	Lb./Box
PECPL-16-IPS-32	1" IPS x 2" IPS Reducer Coupling	1 Ea.	3.1
PECPL-20	1-1/4" IPS Coupling	1 Ea.	2.0
PECPL-20-32	1-1/4" IPS x 2" IPS Reducer Coupling	1 Ea.	3.5
PECPL-24	1-1/2" IPS Coupling	1 Ea.	1.7
PECPL-24-20	1-1/2" IPS x 1-1/4" IPS Reducer Coupling	1 Ea.	2.3
PECPL-32	2" IPS Coupling	1 Ea.	4.0
PERCPL-12	3/4" IPS Repair Coupling	1 Ea.	0.8

