



REF #	PART #	NAME	NOTES
0	5H75012	Burner Bracket	
0	9F10262	Motor(fan)	
0	5H75027	Control Panel	
0	5H75000	Nameplate	
0	5H75034-1	Wiring Diagram	
0	5H78166	Wiring Diagram	Series 103
0	5H75033	Wiring Label	Series 101 & 102
0	5H78165	Wiring Label	Series 103
0	5H74925	Installation Service Manual	
0	5H74999	Lighting Instruction English	
0	5H75183	Lighting Instructions - French	
1	5H77595	Access Panel	
2	5H75015-1	Burner	
3	5H75004	Burner Box	

5	5H74992	<b>Collector Box</b>	
7	5H62892-2	<b>Deflector Blade</b>	
8	5H75189	<b>Exhaust Outlet</b>	
9	5H74973-1	<b>Fan</b>	
10	5H74974-2	<b>Fan Gaurd</b>	
11	5H78147	<b>Flame Rollout (Switch Bracket)</b>	
12	5H75002-2	<b>Flame Rollout Switch</b>	
13	5H56761	<b>Spring</b>	
14	5H75031	<b>Flame Sensor</b>	
15	5H74986	<b>Front Panel</b>	
16	5H76382	<b>Gas Valve (Natural)</b>	Series 101,102,103
16	5H76383	<b>Gas Valve (Propane)</b>	Series 101,102,103
17	3H37360-1015	<b>Heat Exchanger</b>	
18	5H75032	<b>Hot Surface Ignitor</b>	
19	5H75769-1	<b>High Limit Switch (Stalk Mount)</b>	
20	5H75022	<b>Manifold</b>	
23	5H75026-49	<b>Orifice - Natural Gas</b>	More common replacement part
23	5H75026-56	<b>Orifice - Propane Gas</b>	More common replacement part
24	5H74982	<b>Casing</b>	
25	5H75038	<b>Power Exhaust Assembly</b>	
26	5H75030-3	<b>Pressure Switch</b>	
27	5H74988	<b>Side Panel</b>	
28	5H78126-1	<b>Terminal Board</b>	Series 103
29	3H36849-1	<b>Time Delay Relay Replacement Kit</b>	Series 101 & 102
30	5H75029	<b>Control Transformer</b>	
31	5H74990	<b>Unit Mounting Bracket</b>	
37	5H75224	<b>Instruction Sheet</b>	
40	5H75225	<b>Owners Manual</b>	