INDIVIDUAL PARTS	
T-1	Hot renewable seat
T-2	Cold seat O-ring
T-3	Cold renewable seat
T-5	Hot washer screw
T-6	Hot washer
T-7	Cold washer retainer
T-8	Cold washer
TA-10	Flow control spindle
T-11	Cap gasket
T-12A	Cap assembly
T-16	Packing, O-ring and washers
T-17	Packing nut
T-19/20	Dome cover and lock nut
T-21C	Diverter retainer
T-23A	Diverter spindle (Model A) (beige or gray)
T-23B	Diverter spindle (Model B) (black)
T-24	Spindle O-ring
T-26	Plaster shield
T-32	Handle screw with lock washer
T-33	Plug button
T-34	Limit stop with O-ring
T-35A	Hot seat removal tool
T-35B	Cold seat removal tool
T-52A	Stop spindle assembly/ escutcheon screw retainer

INDIVIDUAL PARTS	
T-55B	Stop plaster shield
T-55C	Stop plaster shield removal tool
T-143	Tub/shower dial/emblem
T-144	Shower dial/emblem
T-153	Diverter shaft clip
T-154	Diverter shaft
T3-27	Escutcheon (Model C)
T3-27B	Escutcheon gasket
T3-27D	Escutcheon (Model A and B)
T3-28	Escutcheon screw
T3-29	Dial/emblem assembly
T3-30	Diverter and/or volume handle

COMPOSITE PARTS	
T3-31 INS	Handle insert
T-52	Stop spindle assembly/ escutcheon screw retainer (T-52A) Stop plaster shield (T-55B)
T-101	Acrylic handle: Handle screw (T-32) Plug button (T-33)
TA-4	Hot seat (T-1) Cold seat (T-3) Cold seat O-ring (T-2)

COMPOSITE PARTS	
TA-9	Hot washer screw (T-5) Hot washer (T-6) Cold washer retainer (T-7) Cold washer (T-8) Cap gasket (T-11)
TA-10	Spindle assembly
TA-25A	Diverter/volume spindle (T-23A) O-ring (T-24) for Model A tub/shower valve (beige or gray)
TA-25B	Volume spindle (T-23B) O-ring (T-24) for Model B shower valve (black)
T3-31	Temperature control handle: Insert (T3-31 INS) Handle screw (T-32) Plug button (T3-33R)
T3-31L	Loop style lever handle: Insert (T3-31 INS) Handle screw (T-32) Plug button (T-33)
T3-31S	Solid style lever handle: Insert (T3-31 INS) Handle screw (T-32) Plug button (T-33)T-1
Hot renewable seat	
T-2	Cold seat O-ring



FIGURE 9
Parts Breakdown